



Parts Included in the CCM Kit:

- A – 6” x 9” Flag
- B – Bullet Topper
- C – Molded Mast w/Neoprene Flag Stay
- D – Switch-Blade Bracket
- E – Serrated Lockdown Nut

*For ease of installation, parts A-B-C, come pre-assembled.

Step 1. Start by removing the upper or lower screw of the appropriate side, L - Clutch side or R - Brake side, from the license plate assembly. Keep these parts handy!

Step 2. Align the *unthreaded* mounting hole in the Switch-Blade bracket “D”, to the hole you removed the screw from in Step 1. Place the screw through the license plate and the Switch-Blade. Replace the bolt on the screw and tighten firmly to secure the bracket to the back of the license plate assembly.

Step 3. Take parts ”A-B-C”, and mount in the threaded hole in the Switch-Blade “D”. Twist until the base of the mast fits snugly against the bracket.

Step 4. Now take the serrated lockdown nut “E”, and screw on to the exposed threads under the bracket, tightening firmly, “grabbing” the bracket.

CUSTOM FLAGS AVAILABLE!
NO MINIMUMS REQUIRED!