

TCM Bracket Mount Installation Instructions

Parts Included in this Kit:

- A - 6" x 9" Flag
- B - Bullet Topper
- C - Molded Mast w/ Neoprene Mast Stay
- D - TCM Bracket Mount

Step 1: Start by removing the nut attached to the reinforcement plate, located on the underside of the tour pack.

Step 2: Remove 3M® VHB backing and place the *unthreaded* mounting hole in the TCM Bracket "D" onto the stud protruding from the bottom of the tour pack.

Step 3: Replace the nut and tighten firmly to secure the bracket to the underside of the tour pack.

Step 4: Take parts "A-B-C", and mount in the threaded hole in the Antenna Mount Bracket "D".

Step 5: Now take the serrated lockdown nut "E", and screw onto the exposed threads under the bracket, tightening firmly, "grabbing" the bracket.