



Parts Included in the TCM Kit:

- A - 6" x 9" Flag
- B - Decorative Bullet Topper
- C - Molded Mast w/ Neoprene Flag Stay
- D - TCM.22/.45 – Tour Class Mount
- E - TCM.22 Only - Bullet Topper w/Stud

*For ease of installation, parts A-B-C, come pre-assembled.

Step 1. Start by selecting the preferred mounting location for the TCM. Be sure to check the angle of the flag, smoothness of the mounting surface, and be sure all of the tape will adhere flat to the selected location.

Step 2. Clean the area well, alcohol pads work the best. Be sure the area is dry and there is no soapy residue. Next, peel the 3M® VHB backing off. NOTE – Do Not Touch The Tape Surface. Place the TCM in the desired location. Press firmly in place and allow tape to cure for 72 hours before installing the flag. This will ensure the bond will hold at highway speeds.

Step 3. If the TCM.22 was purchased, the open hole on the TCM can be filled with the extra bullet and stud included with your kit. We recommend using Blue Loc-Tite® in the hole so the bullet does not come out from vibration.

Step 4. After the 72 hours, we again recommend using the Blue Loc-Tite® in the hole for the flag mast. Screw the flag mast into the base and allow a minimum of 2 hours to cure.

CUSTOM FLAGS AVAILABLE!

NO MINIMUMS REQUIRED!